4.3 UNENCRYPTED SIP Trunks

Click on the **New Sip Trunk** to go to the Edit Sip Trunk page.

dit sap frons	
Na me	STATE OF THE PARTY
Dallevar Group	RELOND - GROUP :
Foot A	
Outtoundproxy	
Virtual Diona Number	10-100
Erenann	
Password	
Kogiskor	IXI
Second knows where	M
Fot	20.00
Scarged	8 SO (#
Decum	
lesence GERdry	Amagin v
Design COPO UND	*
Seoure NYOR	
600° Grypton Budde	DESMIT A
Harr Community Calls	26
Net	No.
Drechredge	[2]
tic selepid	W
Audio Torso	No pudio tores 💌
Barkenda	81°C38033 -
Allow	ger-colonialmog/28
Estados	all
Tourised	El .
di lipitate 📳 tedata	

figure 1. "Edit Sip Trunk" form

In figure 1. "Edit Sip Trunk" form you can read an example configuration for an unencrypted SIP trunk. Mandatory fields for the unencrypted configuration are:

- NAME: a meaningful name for this trunk
- HOST: IP address/hostname of the SIP server provided by ITSP
- PORT: this is 5060 by RFC
- TRANSPORT: UDP

• ENCRYPTION: disabled (unchecked)

We do also suggest the following values to be set:

- AUDIO TONES: ON EARLY MEDIA works fine with the Cisco Unified Communications Manager.
- DTMFMODE: choose your values considering the PBX on the other end of the Trunk. Usually we suggest to choose the value RFC2833
 DIRECTMEDIA: enabled (checked)
- **SENDRPID**: enabled (checked)

Other fields in the form depend by your network topology and by the features on the other end PBX.

When you are done with your changes, commit them by clicking on the **Update** icon.

4.2 ENCRYPTED SIP Trunks ZRTP

4.4 Authentication in SIP Trunks