

Blackberry - Change network type

- Disable WiFi and use 3G connection
 - Blackberry OS 5
 - Blackberry OS 7
- Disable WiFi and use 2G connection
 - Blackberry OS 5
 - Blackberry OS 7
- Enable WiFi instead of 3G/2G connection
 - Blackberry OS 5
 - Blackberry OS 7


Disable WiFi and use 3G connection

Blackberry OS 5

Close PrivateGSM (Fig. 1)

Open "**Manage Connections**" under system menu (Fig. 2) and remove the check near "**WiFi**" (Fig. 3) . Select "**Mobile Network Options**" and check that the network mode is set to 3G. (Fig. 4)

Re-launch PrivateGSM and check if it will connect to the server with 3G connection



Blackberry OS 7

Close PrivateGSM (Fig. 1)

Open "**Manage Connections**" under system menu (Fig. 2) and remove the check near "**WiFi**" (Fig. 3). Select "**Networks and Connections**" and open "**Mobile Network**" (Fig. 4). Ensure that the network mode is set to 3G (Fig. 5).

Re-launch PrivateGSM and check if it will connect to the server with 3G connection




Fig. 1



Fig. 2




Fig. 3




Fig. 4




Fig. 5

Disable WiFi and use 2G connection

Blackberry OS 5

Close PrivateGSM (Fig. 1)

Open "**Manage Connections**" under system menu (Fig. 2) and remove the check near "**WiFi**" (Fig. 3). Select "**Mobile Network Options**" and check that the network mode is set to 2G. (Fig. 4)

Re-launch PrivateGSM and check if it will connect to the server with 2G connection




Fig. 1




Fig. 2




Fig. 3




Fig. 4

Blackberry OS 7

Close PrivateGSM (Fig. 1)

Open "**Manage Connections**" under system menu (Fig. 2) and remove the check near "**WiFi**" (Fig. 3). Select "**Networks and Connections**" and open "**Mobile Network**" (Fig. 4) . Ensure that the network mode is set to 2G (Fig. 5)

Re-launch PrivateGSM and check if it will connect to the server with 2G connection




Fig. 1



Fig. 2




Fig. 3




Fig. 4




Fig. 5

Enable WiFi instead of 3G/2G connection

Blackberry OS 5

Close PrivateGSM (Fig. 1)

Open "Manage Connections" under system menu (Fig. 2) and add a check near "Wi-Fi" (Fig. 3). If no WiFi network is configured on the device, configure a new WiFi connection under "Wi-Fi options"

Re-launch PrivateGSM and check if it will connect to the server with WiFi connection




Fig. 1




Fig. 2




Fig. 3

Blackberry OS 7

Close PrivateGSM (Fig. 1)

Open "Manage Connections" under system menu (Fig. 2) and add the check near "WiFi" (Fig 3). If no WiFi network is configured on the device, configure a new WiFi connection under "Networks and Connections" "Wi-Fi network".

Re-launch PrivateGSM and check if it will connect to the server with WiFi connection




Fig. 1



Fig. 2




Fig. 3