

# Glossary

## Glossary

### PBX

A **private branch exchange** (PBX) is a telephone exchange that serves a particular business or office, as opposed to one that a common carrier or telephone company operates for many businesses or for the general public.

**PBXs** make connections among the internal telephones of a private organization—usually a business—and also connect them to the public switched telephone network (**PSTN**) via **trunk** lines.

### Trunk

A **trunk line** is a circuit connecting telephone switchboards (or other switching equipment), as distinguished from local loop circuit which extends from telephone exchange switching equipment to individual telephones or information origination/termination equipment.

When dealing with a **private branch exchange (PBX)**, trunk lines are the phone lines coming into the **PBX** from the telephone provider. This differentiates these incoming lines from **extension** lines that connect the **PBX** to (usually) individual phone sets.

### Extensions

A **telephone extension** is an internal telephone line attached to a Private branch exchange (PBX). The PBX operates much as a community switchboard does for a geographic telephone numbering plan and allows multiple lines inside the office to connect without each phone requiring a separate outside line. In these systems, a dialer usually has to dial a number to tell the PBX to connect with a landline to dial an external number. Within the PBX, the user merely dials the extension number of the person. Each phone line may be extended up to a fixed maximum.

### Secure Call

A **Secure Call** is a voice connection which can't be wiretapped and it runs over Voice Over IP (VoIP) communication protocol.



Unknown macro: 'builder-show'



Unknown macro: 'builder-show'

### PrivateServer

**PrivateServer** is the **PBX** committed to perform **Secure Calls** both **end to end** and **end to site**. It differs from a standard **PBX** for exposing just the **Secure Call** service to VoIP **PrivateWave** clients and can be connected to a standard **PBX** via **SIP Trunks** if configured accordingly.

### PrivateWave

**PrivateWave** is the **VoIP client for Secure Calls** connections. It has to be used along with **PrivateServer**.



Unknown macro: 'builder-show'

### Jitter

In VoIP systems audio signal is split into multiple packets, which are sent over network. Due to network equipment behavior, packets flow is never regular and constant. Especially on mobile/radio networks packets are delivered in bursts, leading to irregular and variable latency. **Jitter** is the variation in latency as measured in the variability over time of the packet latency across a network.

### Automatic Activation

The **Automatic Activation** is the way of create new users automatically without any need they interact with anybody. As from user's side the procedure is that he/she gets first an **invite SMS** or **E-Mail** useful to download the application `PrivateWave` and then a **configuration SMS** or **E-Mail** which provides automatic configuration of the client itself. All the user has to do is to follow the links into both the Texts/E-mails and `PrivateWave` would go automatically on line.

## Provisioning

The **Provisioning** is the configuration needed for delivering both for the `PrivateWave` application and its configuration and nowadays it's used by the **Automatic Activation** only.

## Presence

The **Presence** is how we call the user's status, also known as the user's reachability. By checking an user's Presence it is possible to know if a he/she is on line and can receive a secure call before trying to.

## Audio Messaging

The **Audio Messaging** is the means used by `PrivateWave` for communicating to an user about the failed calls. You have several messages that can be spoken and each of them can be localised in English, French, Italian, Spanish and German.

## Secure Message

**Secure Message** is a text message that can be sent and received only by using `PrivateWave` and that shares the same communication infrastructure of Secure Call. The maximum length of each message is 160 character.

## Call Roaming

**Call Roaming** is specific configuration set up by default on both `PrivateServer` and `PrivateWave` . It let any call to continue even if one network change event occur (e.g: wi-fi network got lost in favour of 3g data mobile one). During network change itself the call is muted but as soon as any connection is again available, then voice stream is back streaming. Call roaming is subject to `Strictrtp` and `Rtp` timeout options in `PrivateServer` .