# **PSAM 2.4 Advanced configurations**

Some advanced configuration settings about the PrivateServer behavior.

# 2.4.1 SIP/TLS

SIP/TLS is about configuring the encrypted communication channel among PrivateServer and its clients. The configuration form is reachable by the SIP /TLS main menu entry.

SIP/TL	SIP/TLS Configuration			
Use default				
	Ciphers list	AES256-SHA:RC4-SHA	1 Reset	
📄 Upd	ate			

figure 1. Cipher list configuration form

From the figure 1. Cipher list configuration form you can set up the cypher list of the PrivateServer. This is the list of accepted cipher suite, using OpenSSL format. Check at http://www.openssl.org/docs/apps/ciphers.html#CIPHER\_LIST\_FORMAT. Usually you can leave the default values.

# 2.4.2 RTP

(i)

"The Real-time Transport Protocol (RTP) defines a standardized packet format for delivering audio and video over IP networks" (quote from Wikipedia).

₥	Home					
---	------	--	--	--	--	--

# Edit Rtp Network Config

Use default		
	Rtpstart	15000
	Rtpend	18000
	Rtpchecksums	<b>I</b>
	Strictrtp	
📄 Upa	late	

figure 2. RTP configuration form

In this form that you get by the **RTP** main menu entry, you can set up the voice transport features. **Rtpstart** and **Rtpend** define the RTP port range reserved for RTP traffic.

4 UDP ports are reserved for each concurrent call, thus you can do your math on the RTP range extension required in your configuration, multiplying the number of foreseen concurrent calls by 4.

In the example shown in figure 2. RTP configuration form you see:

18000 - 15000 = 3000 ports available. This means 3000/4 = 750 concurrent calls threshold.

The **Rtpchecksums** enable the application checksum over UDP encrypted voice transmission. This is an error detection commodity, which adds 16 bits per packets payload.

Strictrtp Enables the strict RTP protection. This will drop RTP packets that do not come from the source of the RTP stream. This option is disabled by default.

## 2.4.3 Jitter Buffer

Jitter is the variation in latency as measured in the variability over time of the packet latency across a network. The consequences of jitter, often called *jitter ing*, are a voice communication with gaps in it or stirring metal voice effect. Mostly on a GPRS and EDGE network (and in general in a mobile network environment), the jitter is a sensible problem to face. To cope with jittering issues, a **jitter buffer** produces a smooth and regular audio output, just adding some more latency.

PrivateGSM and VoIP devices already have an embedded jitter buffer, so it is not required to enable it on PrivateServer also. For very old devices and SIP trunks which have an inefficient jitter buffer, it is possible to enable it on PrivateServer.

<u>↑</u> Home	
---------------	--

Edit J	itter Buffer Confi	g
Use defaul	t	
	Enable	$\checkmark$
	Force	V
	MaxSize	500
	Resync Threshold	5000
	Impl	FIXED \$
	Log	
🕞 Up	odate	
		figure 3. Jitter Buffer configuration forr

The **jitter buffer** is an elastic buffer in which the signal is temporarily stored and then retransmitted at a rate based on the average rate of the incoming signal. Checking the **Enable** checkbox you allow PrivateServer to perform such jitter buffering in general, when needed.

The Force option obliges PrivateServer to create the jitter buffer over any new communication channel.

MaxSize is the max length of the jitterbuffer in milliseconds.

**Resync Threshold** is the buffer synchronization threshold. It's useful to improve the quality of the voice, with big jumps in/broken timestamps. Defaults to 1000.

Impl is the Jitterbuffer implementation, used on the receiving side of a SIP channel. Two implementations are currently available:

- FIXED (with size always equals to jbmaxsize)
- ADAPTIVE (with variable size)

Defaults to FIXED.

Log enables jitterbuffer frame logging. Defaults to "no".

#### The following services need to be restarted to apply your changes: asterisk.

### 🔬 Home

# Edit Jitter Buffer Config

Iitter Buffer Config updated

figure 4. The Management console asks to restart the service

To apply your changes just press the **Update** button and the management interface will ask you to restart the asterisk service in order to apply your new configuration, as shown in

### 2.4.4 Obfuscation

The **Obfuscation** is an internal VoIP communication stealth mode. This is a useful countermeasure to bypass VoIP blocks and censorship, as it masks the data.

Home		
dit Obfuscation Config		
de	OFF 🛟	
у	0	

figure 5. Edit the obfuscation parameters

The configuration is quite simple. Mode enables/disables the obfuscation mode.

Key is a shared numeric key to be reported on the clients configuration as well.

To avoid calls problems such as abruptly interrupted calls you make sure the obfuscation mode and key are equally set up on the server and the clients.

### 2.4.5 NAT Configuration

If you are using the appliance in an internal network then it's most possible that you need to configure the **NAT** option. NAT stands for **Network Address Translation** and it's commonly used to let services on a private IP address to be reachable by a public IP address.

# NAT Configuration

Use default		
	NAT	NO 🛊 🗊
	External media address	
	External SIP address	
	External port	143
	Keep-alive Frequency	
📴 Update		

#### figure 6. NAT configuration form

Apart from your router/firewall configuration (please check PrivateGSM installation pre-requisites) and your network design/topology, from PrivateServer point of view the only known thing is that the appliance is configured on a private IP address but the requests of the encrypted voice service are made to an external and public IP address. To avoid wrong replies the PrivateServer must know of this setup and be configured accordingly. Thus if you fall in the described scenario access to the "NAT Configuration" form (showed in figure 6. NAT configuration form) using the "NAT" link under "Server Configuration".

By default this option is disabled, so to enable it you first need to select "YES" in "NAT" option. If you have enabled the NAT then it's mandatory to configure the remaining options as well.

To better understand what a keep-alive is, please refer to PSOM 1.0 Groups.

#### External media address

This is the public IP address used for the RTP delivery. It means that this is the secured voice IP you want to use.

Possible Misconfiguration
Unless you need to specify for some reason a specific IP address for RTP, you'd better leave this field empty and let Asterisk do the job for you!

#### **External SIP address**

This is the public IP address used for the SIP delivery. It means that this is the IP you want to use for SIP signalling.

### **External port**

If you want to perform a **PAT** (Port Address Translation) in addition to the NAT, then please use this option to explain to the appliance which **port number** is used on the **external** interface for providing the **encrypted SIP service**.

# 2.4.5.1 Keep-alive Frequency

If you are using the keep-alive option (please refer to PSOM 1.0 Groups) then you may find this option handy. You can define here how many seconds should pass between each keep-alive request sent by the server to each client configured with the keep-alive option.

Please keep in mind that the **default** keep-alive **timeout** is **60 seconds** and thus it can lead to a quick battery drain since the radio system on the mobile device could never be idled.

If any mobile user has been configured with the keep-alive option on, then we **strongly suggest** you to set the **keep-alive Frequency** to **180 seconds** (i. e. 3 minutes) at least in order to save battery life.

PSAM 2.3 Certificates management PSAM 2.5 Clock and Language Configuration