

PrivateGSM - Automatic activation

The SIP account can be configured automatically by the Enterprise VoIP Security Suite administrator. Two different SMS will be sent to the user mobile phone:

- an **installation SMS** containing the PrivateGSM software download instructions
- a **configuration SMS** containing a clickable link

Once PrivateGSM is installed using the first SMS, you must click the link in the second SMS. PrivateGSM will be launched automatically and the initial wizard will help you to configure and test the provisioned configuration.





With a provisioned configuration, the application settings are not editable by the user. The user can see only a restricted set of the application settings. The application settings are fully editable only if the SIP account is manually configured during the initial activation wizard.






Once you accepted a provisioning link from a particular PrivateServer, for security reasons PrivateGSM will tie itself to that server and will accept further provisioning links from that server. You should reset PrivateGSM to factory defaults (from the Settings view) to be able to accept links from other servers.



Blackberry

Step 1	Step 2
Click on the provisioning link	Confirm PrivateGSM activation
	

iPhone

Step 1	Step 2	Step 3
Click the provisioning link	Select "Open in PGSM Ent"	Confirm PrivateGSM activation
		

Android

Step 1	Step 2
Click the provisioning link	Confirm PrivateGSM activation
	

PrivateGSM Professional Activation Wizard

Start PrivateGSM